

90cm induction cooktop with ProCook function, FlexiBridge, touch slide controls, XL zone and Hob2Hood.





Product Details

FEATURES

ProCook function

FlexiBridge function

Hob2Hood Hob2Hood automatically adjusts your hood settings so you can focus on creating delicious dishes. XL Zone

Touch slide controls

OptiHeat™ control
The OptiHeat™ control helps
you make the most efficient
use of residual heat. It
advises 3 levels of residual
heat whether the heat zone is
still hot enough to cook with,
hot enough to keep food
warm, or simply hot to touch.

Automax

Pause Function
The pause function sets
zones to the lowest setting to
keep dishes warm and
prevent overcooking.

Minute Minder

Oko timer

Function control lock

BENEFITS

ProCook

At the touch of a button, the FlexiBridge cooking zone switches to three pre-set temperature levels: high, medium and low so you can simply move the pan to seamlessly go from boil to simmer.

Combine zones to cook more with FlexiBridge Activated by a dedicated touch key and seamlessly controlled through one control, FlexiBridge is perfect for cooking larger dishes.

Hob2Hood

Leave Hob2Hood to regulate the fan while you concentrate on the key moments involved in getting your dish just right. It will automatically control your rangehood's fan and lights. OptiHeat™ control by monitoring each heat zone
The OptiHeat™ control helps you make the most efficient use
of residual heat. It advises 3 levels of residual heat whether
the heat zone is still hot enough to cook with, hot enough to
keep food warm, or simply hot to touch.



AutoMax

Our AutoMax cooking function provides fantastic automatic zone control. After you have selected the AutoMax function, it will bring the zone up to the boil and will then reduce it to your pre-selected power level for the remainder of the cooking time.

Touch slide controls

Precise heat control in an instant. Heat levels can be adjusted quickly, easily and accurately.



Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	5
Cooktop type	induction
Materials/Colour	black ceramic glass
Removable trim (for cleaning)	No

DIMENSIONS

Total product height (mm)	48
Total product width (mm)	910
Total product depth (mm)	520
Cut out width (mm)	880
Cut out depth (mm)	490
Cut out height (mm)	44

CONTROLS

Controls of Cooktops	Touch and Slide controls
Position of controls	front
Functions of Cooktops	automatic switch off,AutoMax automatic heat up,acoustic signal,booster,Hob2Hood,FlexiBridge,timer,pause,ProCook
Indicators/display	fault indicator,3 level residual heat indicator
Features of Cooktop	minute minder,function lock,sound off,pot sensors,Hob2Hood Connectivity,FlexiBridge zone

ELEMENTS/BURNERS

Left front zone FlexiBridge Left front Watts 2300 Left front boost 3200 watts Left front 220 diameter mm



CONTROLS

Timer of Cooktop Oko timer, CountUp, Minute minder

LEFT REAR ZONE

Left rear zone	FlexiBridge
Left rear watts	2300
Left rear diameter mm	220

CENTRE FRONT ZONE

Centre front zone	induction
Centre front Watts	1800
Centre front diameter mm	280

RIGHT FRONT ZONE

Right front zone	induction
Right front Watts	1400
Right front diameter mm	145

RIGHT REAR ZONE

Right rear zone	induction
Right rear watts	2300
Right rear diameter mm	210

ELECTRICAL SPECIFICATIONS

Connected load KW	7.4
Type of connection	hardwired

SHIPPING

Shipping Weight (Kg)	20.89
Pack Dimensions Height (mm)	115
Pack Dimension Width (mm)	1170






SHIPPING

Pack Dimension Depth 630 (mm)



Dimensions





Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

Electrolux Home Products warrants that for domestic applications the AEG appliances featured are free from defects in materials and workmanship for 5 years (3 months warranty for commercial applications). All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 664 fax: 1800 350 067

email: customercare@aegaustralia.com.au

web: www.aeg.com/au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 0800 10 66 10

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.aeg.com/au