

CLARK[®] UTILITY

UTILITY MINI 16.5 LITRE LAUNDRY TUB & CABINET

LAUNDRY TUB AND CABINET INSTRUCTION

If your tub and cabinet have been specified with a bypass then fit this first as detailed in the instructions on the bag.

NOTE: Edges on cabinet may be sharp. Ensure protective gloves are worn when handling cabinet.

1. Lift tub out of cabinet.
2. Measure out the area where the cabinet and tub is going to sit. Ensure that the floor is clear of rubbish and that the wall(s) and floor have no obstructions which may interfere with the cabinet.
3. Check that pipes and taps will match up with the tub. If any pipes are to pass through the wall of the cabinet measure up and cut these holes now.
4. The door may be reversed for left or right hand opening

To reverse door opening.

- a. Remove hinge rod from cabinet and door.
- b. Remove plastic striker plate and hinge base from cabinet. Push striker plate and hinge base into corresponding holes on the opposite side of the door opening.
- c. Replace door and hinge assembly. Test the door to ensure that it opens properly.
5. Place the cabinet in position on the floor and level the top of the cabinet with a spirit level. The cabinet should be propped level with appropriate materials if the floor is not level. Alternatively adjustable feet can be purchased from your supplier that attach to the cabinet to make this job easier and more professional.
6. Place tub on cabinet and check that it is level also. Plumb tub and ensure that the tub drains and that there are no leaks.

